



Oil-Only MultiLaminate Pads #WPL100M - 15" x 19", 100 pads/package



MultiLaminate Mat Pads are long-lasting and durable for rugged applications.

- **Tear-Resistant — Outlasts Standard Mats:** Outer layers of tough-skinned, HeavyWeight SpunBond material resist abrasions and tears — can withstand rough handling and won't tear apart when pulled or positioned under equipment. It's ideal as a liner for oily parts and tools or for use in rugged applications near machinery.
- **Absorbent Inner Layer:** High-loft MeltBlown inner layer draws and holds liquids from outer layers. Absorbs high volumes of liquid fast. Color-coding helps you visually identify the right sorbent for your needs. Bright white designates Oil-Only sorbency for oil and other petroleum-based fluids — but not water; makes it easy to identify when saturated.
- **Low Lint for Sensitive Jobs:** Outer SpunBond layers are constructed of continuous strands of polypropylene fibers — interwoven to virtually eliminate fibers from becoming detached and contaminating equipment, tools or parts.
- **Multi-Perforations Save You Money:** Pads are perfed vertically at 7.5". Tear off only what you need — save money!



Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com

WPL100M Specifications

Dimensions:	15" W x 19" L
Shipping	15" W x 19" L x 12.5" H
Dimensions:	
Sold as:	100 pads per package
Color:	White
Composition:	Polypropylene
Absorbency:	Up to 23.4 gal. per package
Absorbency per:	Up to 29.95 oz. per pad
# per Pallet:	36
Basis Weight:	MediumWeight
Incinerable:	Yes
Ship Class:	150

Metric Equivalent Specifications

Dimensions:	38.1cm W x 48.3cm L
Shipping	38.1cm W x 48.3cm L x 31.8cm H
Dimensions:	
Absorbency:	Up to 88.6 L per package
Absorbency per:	Up to 885.6 mL per pad

WPL100M Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Material Safety Data Sheet (MSDS)



Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com