

3

Easy Scrub Flat Mop System

Technical Data

July 2005

Description:

3M™ Easy Scrub Flat Mop System is a unique set of cleaning tools designed to make floor cleaning and disinfecting faster, easier and safer. The system features a lightweight handle with liquid-on-demand dispensing, flat mops with special dual-fiber construction, and buddy jug for refilling the handle without returning to the closet.

Special Features:

Easy Scrub Flat Mop Tool

- Lightweight anodized tool is durable & corrosion resistant
- Swivel head for easy maneuvering & effective baseboard cleaning
- Solid vinyl grips are easy to clean & disinfect
- Viewing window enables you to easily tell when the handle is filled
- Solution filled handle dispenses liquid as needed
- Closed system helps prevent contamination of solution

Easy Scrub Flat Mop

- Dual-fiber construction produces less drag and makes the tool easier to maneuver
- Dual-fiber construction for better cleaning & mark removal
- Durable, machine washable, bleach safe

Note: Bleach may cause slight yellowing of the Velcro® backing fabric

Easy Scrub Buddy Jug

- 2 ½ -gallon closed container
- Helps eliminate the need for unsightly open buckets
- Closed container helps prevent contamination of solutions
- Fast & easy filling without returning to the closet

Packaging:

Flat Mop Tool – 1/box
Buddy Jug – 12/box
Flat Mops – 10/pkg (100/case)

General Use Directions:

Preparation

1. Fill the Easy Scrub Buddy Jug, with the appropriate cleaner or disinfectant, using the 3M™ Twist 'n Fill™ Dispenser.
2. When filled, cap the Buddy Jug and place on cart.
3. Attach mop holder to handle:
 - Depress the spring-loaded metal buttons on the mop holder.
 - Slip the end of the handle over the top portion of the holder.
 - Adjust handle until buttons lock into place.
4. Load cart with the Flat Mop Tool and several clean, dry Easy Scrub Flat Mops.
5. Proceed to the first patient room or job site.

Note: The tool is safe for use with general cleaners or disinfectant cleaner with a pH in the range of 7 to 10.

Filling the Mop Tool Handle

1. Remove plug in handle by gently pulling up on dispense button.
2. Once removed, allow plug to hang freely.
3. Place open end of handle under the spigot and turn handle so window opening is facing up.
4. Open small vent cap slightly and turn spigot to fill handle.
5. When liquid appears in window, turn spigot to off position.
6. Replace plug in handle and tighten vent cap.

Note: For safety of personnel, do not use filled tool to clean vertical surfaces like walls and ceilings.

Ready to Clean

1. Place a clean Easy Scrub Flat Mop, face down on the floor.
2. Position the mop holder over the mop & push the holder down to fasten mop.
3. The red arrow on the lower handle indicates the outlet for the solution.
4. Depress the button until small puddles of solution have been dispensed.

5. Push the flat mop through the solution on the floor to thoroughly moisten the mop.
6. Clean the floor using a figure-eight, S-stroke or whatever method is comfortable for the user.
7. Apply additional liquid as needed.

Note: When disinfecting, dispense enough liquid to comply with the manufacturer's recommended dwell time.

Clean-up

1. Remove dirty mop from holder & bag for laundering.
2. Load a clean mop and refill handle if necessary.
3. Change mop after each room or follow the policy used in your facility.
4. At the end of the shift, empty the handle, fill it with water and flush out the handle.
5. Wipe the outside of the handle with disinfectant.
6. Empty handle, leave plug out and hang with open end down to dry.

Note: To ensure easy removal of the dispense button assembly; lubricate the large O-ring located on the inside of the plug. Apply clean, non-staining lubricant such as petroleum jelly.



Product Specifications:

Handle: 54"

Mop holder: 3 ¾" x 16"

Microfiber mop: 5 ½" x 18"

Buddy Jug: 7 ½" x 9 ½" x 9 ½"

Easy Scrub Flat Mop Tool:

empty - 30 ounces (1.9 lb)

filled - 39 ounces (2.3 lb)

Precautionary Summary:

According to FIFRA, this applicator does not require EPA registration

3M Branch Sales Offices

ANCHORAGE

11151 Calaska Circle
Anchorage, AK 99515
Telephone: 907/522-5200
Facsimile: 907/522-1645

HONOLULU

4443 Malaai Street
Honolulu, HI 96818
Mail to: P.O. Box 30048
Honolulu, HI 96820
Telephone: 808/422-2721
Facsimile: 808/422-9557

CONTINENTAL UNITED STATES

Customer Service Department
3M Center Building 223-5S-07
St. Paul, MN 55144-1000
Order Entry: 800/852-9722
Facsimile: 800/447-0408

CANADA

1840 Oxford Street East
London, Ontario, Canada
N5V 3G2
Mail to: P.O. Box 5757
London, Ontario, Canada
N6A 4T1
Telephone: 800/364-3577
Facsimile: 800/479-4453

Important:

The information provided in this report is believed to be reliable; however, due to the wide variety of intervening factors, 3M does not warrant that the results will necessarily be obtained. All details concerning product specifications and terms of sale are available from 3M.



Commercial Care Division

St. Paul, MN 55144-1000
1-800-852-9722
www.3M.com/commcare

3M and Twist n' Fill are trademarks of 3M Company.

Copyright © 2005, 3M IPC. All rights reserved.